INSTALLATION INSTRUCTIONS





ELECTRICAL SHOCK HAZARD

READ, UNDERSTAND, and **FOLLOW** these instructions before installing the equipment.

WARNING

Disconnect the Electrical supply power at the service panel (fuse or circuit breaker box). Failure to do so could result in serious injury or death. Only qualified electricians should install this fixture and the installation MUST conform to the Electrical Code and all local codes and ordinances. Ensure that only proper tools, materials, and equipment are used to complete the installation.

SAFETY

- Proper grounding is required to ensure personal safety.
- Fixture should be mounted in locations where unauthorized personnel will not readily subject it to tampering.
- Do not use this equipment for anything other than its intended purpose.
- Servicing this equipment should be performed by qualified service personnel.
- Save these instructions.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the
 FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential
 installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in
 accordance with the instructions, may cause harmful interference to radio communications.
- Changes or modifications to this unit not expressly approved by the party responsible for compliance Could void the user authority to operate the equipment.

INSTALLATION

- 1. Rotate the fixture head 90 degrees, with the LED panel facing downward.
- 2. Tighten two pairs of bolts located on the sides of the bracket to secure the fixture head. Bolts should be tight enough to prevent shaking of head.
- Loosen the bottom bolts of the fixture. Make connections as per wiring diagram. Place fixture on pole tenon of a maximum diameter of 3 inches (76.2 mm), rotate fixture if needed to adjust viewing angle, and tighten bottom bolts to secure light fixture to pole.
- 4. The 35W, and 75W fixture come included with a CCT switch. To change color temperature (CCT), remove the top cover of the fixture head to configure color switch. Available color temperatures (CCT) are 3000K, 4000K, and 5000K. After, reassemble the top cover.

WIRING

- Check that the line voltage is correct.
- Connect fixture GROUND (green) wire to power supply GROUND (green) wire.
- Connect fixture WHITE wire to power supply NEUTRAL wire.
- Connect fixture **BLACK** wire to power supply **LINE** wire
- If the fixture includes 0-10V dimming functionality, connect **GREY** and **VIOLET** wires to the dimming controller.



